

RinkMusic™ RMC-1000 System

COACH INFO



RMP-1000 CONTROL PANEL



RMC-1000 MAIN SYSTEM CPU and RMT-1000 KEY TAGS
(shown with optional touch screen)

The RinkMusic™ system was developed to provide a convenient way for skaters to transport, play and control their music programs without the cumbersome task of using cassettes or CDs.

As you know, cassettes, on many occasions get damaged or are "eaten" by the cassette player. The CD, on the other hand, tends to get scratched and therefore unplayable and certainly from time to time there is no one to play the music at the arena.

With this new technology, music is stored digitally on the RinkMusic™ system. The music is given to the rink via a CD or cassette, and is uploaded. When a RinkMusic™ Key is presented to the Key Reader, the music program will be loaded for play. If another music program is currently playing, the new music program will be placed in the music queue. The skater's name will be announced alerting them that their music is about to play. This is all done automatically starting with the swipe of a RinkMusic™ Key.

Benefits

With the RinkMusic™ System:

- your students will know who they follow and not stand around waiting their turn.
- your students won't need help playing their music.
- no more problems with lost or damaged CDs or cassettes.
- no more running to turn your student's music volume up or down.
- once a music programs' volume is adjusted, it is remembered for subsequent play.

Features

- By using your coach key you can move your skater forward in the queue.
- Keys are easily replaced.
- All your student's music is stored digitally on the RinkMusic™ system.
- Music can be uploaded to the RinkMusic™ Internet Server and then downloaded to any participating rink.



RinkMusic™ Control Panel RMP-1000

